

DESCRIPTION

The versatile P3OCW5 photodetector module can be used for all three modes of photomultiplier operation – pulse counting, analogue detection or photon counting. It comprises a 30 mm diameter, fast end-window photomultiplier and a –HV power supply, encapsulated within a cylindrical mumetal* case. A photomultilier with a bialkali photocathode is used for blue-green detection, and an S20 photocathode is used for red detection. The signal output is connected directly to the pmt anode allowing the user freedom to work into a range of electronic circuitry.

The effective photocathode diameter is 25 mm. The photomultiplier high voltage is set by any one of the two methods described in the **installation and operation section**.



APPLICATIONS

- Battery powered instruments
- Portable instruments
- Industrial instruments
- University research

FEATURES

- Easy to operate
- Compact cylindrical geometry
- 2 modes of HV control
- Direct connection to the anode

www.sens-tech.com info@sens-tech.com



CHARACTERISTICS

PHOTOCATHODE TYPE	OUTPUT PULSE INTO 50Ω
Bialkali or S20	Output pulse rise time 4.5 ns
PHOTOCATHODE ACTIVE DIAMETER 25 mm	Output pulse fwhm 7.5 ns
SPECTRAL RESPONSE RANGE	OUTPUT IMPENDANCE
See curves	>10 ⁸ Ω
PEAK QE (TYP)	DARK COUNTS AT 20 °C (TYP.)
See curves	100 s ⁻¹
POWER INPUT (TYP.)	DARK COUNTS AT 20 °C (MAX.)
+5 V, 35 mA	200 s ⁻¹
WARM UP TIME	HV / CONTROL VOLTAGE
< 10s	1000:1
WEIGHT 285g	TEMPERATUREOperating+5 °C to +55 °C
OPERATING POSITION Any	Storage -40 °C to +55 °C
FINISH Matt black	



PHOTOCATHODE SPECTRAL RESPONSE



FREQUENCY RESPONSE



MODES OF OPERATION

Pulsed applications

To observe fast pulses, either with an oscilloscope or via a fast voltage amplifier connect the free end of the coaxial cable to 50 Ω . For slow pulses of rise time ~ 1µs, the terminating resistor may be increased to 1 – 10 k Ω to give higher amplitude pulses.

Analogue applications

The bandwidth attainable with 50 Ω termination is given in the figure. Lower bandwidths may be realised by a parallel combinations of R and C connected to the anode lead. If more gain is required, or a low impedance drive capability, then the RC combination must be placed in the feedback path of a transimpedance amplifier.



PHOTON COUNTING

The module may be used for photon counting by connecting it to an external amplifier-discriminator. Extended dynamic range can be obtained by dark count subtraction and by dead time correction to compensate for departure from linearity at high count rates.



INSTALLATION AND OPERATION

Each module is supplied with test data. Wherever possible installation should be carried out in subdued light. Exposure to strong lights, particularly those containing a high uv content, can result in a temporary increase in dark counts.

Remove the protective cap from the module. If necessary, the photomultiplier window can be cleaned using a lens tissue moistened with alcohol. Do not use any other solvent.

Mount the module and make power input and signal connections. Where the signal lead is longer than 200 mm, it should be terminated into 50 Ω . Do not expose the photomultiplier tube photocathode to strong lights while the module is energised.

PROGRAMMING OPTIONS FOR INTERNAL HIGH VOLTAGE POWER SUPPLY

+5 V to +8 V

0 V

nc

control

+0.3 V to +1.8 V

monitor



nc: no connection - isolated lead

monitor: 1/1000 of voltage applied to photomultiplier

www.sens-tech.com info@sens-tech.com

P30CW5 Series data sheet Page 4 of 5



OUTLINE DRAWING MM



WARNING

The pmt cathode is operated at +HV. To guarantee stable performance and for safety reasons, the entire window must be isolated by a distance of at least 3 mm from any ground plane. The use of PTFE for insulation purposes is recommended.

No attempt must be made to repair or dismantle this product. High voltage used within the module may present an electric shock hazard.

Operation beyond the maximum ratings, or reversal of the input voltage may result in loss of performance or permanent damage to the product.

*mumetal is a registered trademark of Magnetic Shield Corporation

SENS - TECH

www.sens-tech.com info@sens-tech.com The company reserves the right to modify these designs and specifications without notice. Developmental devices are intended for evaluation and no obligation is assumed for future manufacture. While every effort is made to ensure accuracy of published information the company cannot be held responsible for errors or consequences arising therefrom.

An ISO 9001 registered company

P30CW5 Series data sheet Page 5 of 5